

Thank you for purchasing our product.  
Please read this instruction sheet carefully before using, and use it safely and responsibly. After reading, please keep this instruction sheet for future reference.

For detailed instructions for using the product, please access the SHIBUYA website and download the user manual.

## Caution and Warning

- Shibuya products are designed with great care for safe use. However, due to the nature of the products, certain parts contain sharp edges. Please take care when handling them.
- For safe use, please check the points below before and after shooting:
  1. Is the plunger firmly attached to the bow riser?
  2. Are all set screws firmly fastened?
  3. Do all moving parts work smoothly?
  4. Is the plunger tip in good condition – no fracture or bending?In case you identify a problem, discontinue the usage immediately and contact your retailer about the issue.
- Keep out of the hands of small children, for some parts can be hazardous when swallowed.
- Store the packaging materials out of reach of small children.
- Do not use the product for anything else but Recurve Archery.
- Do not expose the product to prolonged excessive heat.

## Cautions for safe handling

- Screws are loose upon initial receipt. Before using, please adjust it according to your bow setting, and make sure to tighten all screws.
- Over-tightening of screws may lead to damage to the product. Pay careful attention when adjusting.

## Product Warranty

- The warranty period for this product under normal usage is 1 year after your purchase.
- In the case of a fault caused by a manufacturing problem, the product will be repaired or replaced free of charge (Customers are responsible for its shipping cost).
- Warranty is limited to the first purchasing party - only the customers having purchased the product directly from a retail store.
- Damage caused by the following is excluded from warranty coverage:
  1. Any damage beyond normal use; such as being pushed over, dropped, made impact with hard objects, or anything else that gives excessive stress on the equipment.
  2. Damage caused by over-tightening of screws or tightening of screws at an unintended angle.
  3. Natural wear-out and tear of the plunger tip.

この度は、シブヤ製品をお買い上げいただき誠にありがとうございます。  
ご使用の前に、この取扱説明書をよくお読みのうえ保存し、本製品を安全にお使いください。

製品についての詳しい使用方法については、渋谷アーチェリー公式ホームページにアクセスいただき、製品使用マニュアルをダウンロードし、よくお読みください。

## 注意と警告

- シブヤ製品は安全に充分配慮しておりますが、製品の性質上、鋭利な部位がある部品もございます、取扱いには充分ご注意ください。
- 安全にお使い頂くために、下記の定期点検をお願いいたします。
  1. 弓にしっかり取り付けられているか？
  2. 各ねじ部がゆるんでいないか？
  3. 可動部の動きに異常がないか？
  4. フランジャーチップに折れ・曲がりなどの異常がないか？異常が見つかった場合は使用を中止し、ご購入店にご相談ください。
- 本製品や部品の一部をお子様が誤って飲み込む事がないようご注意ください。
- 梱包袋などを小さなお子様の手の届くところに置かないでください。
- リカーブボウでのアーチェリー以外に使用しないでください。
- 高温になる場所に置かないでください。

## 取扱い上の注意

- 本製品の初期出荷状態では、各部のねじが十分に締まっていません。ご使用前に必ずご自分の弓具に合わせて調整後、各ねじ部を確実に締めてください。
- 各ねじ部を必要以上に強く締めると破損の原因となります。十分ご注意ください。

## 製品の保証について

- 通常の使用状況の範囲内での本製品の保証期間はご購入後1年間です。
- 保証期間中、製造上の不備による故障につきましては無償で修理・交換致します(送料はお客様負担とさせていただきます)。
- 本製品の保証は販売店より新品を直接購入したお客様に限られます。
- 下記の故障の場合は保証の対象外とさせていただきます。
  - ① 弓を倒す、落下する、硬い物にぶつけるなど、通常の使用範囲を超える負荷がかかった場合。
  - ② ねじの締めすぎや、無理な状態で締め付けに起因する変形・破損。
  - ③ フランジャーチップの摩耗による減り。

3-7-4 Ikejiri, Setagaya-ku, Tokyo 154-0001 Japan  
Tel : +81-3-5430-6811  
〒154-0001 東京都世田谷区池尻3-7-4  
Tel : 03-5430-6811  
<http://www.shibuya-archery.com>  
E-mail : [archer@shibuya-archery.com](mailto:archer@shibuya-archery.com)